

Q: How many WiFi channels are available?

A: The number of available channels depends on the geographical region.

Channel number	Channel centre frequency (MHz)	Europe	United States Canada	China South Korea Taiwan	Japan
1	2412	X	X	X	X
2	2417	X	X	X	X
3	2422	X	X	X	X
4	2427	X	X	X	X
5	2432	X	X	X	X
6	2437	X	X	X	X
7	2442	X	X	X	X
8	2447	X	X	X	X
9	2452	X	X	X	X
10	2457	X	X	X	X
11	2462	X	X	X	X
12	2467	X			X
13	2472	X			X
36	5180	X	X		X
40	5200	X	X		X
44	5220	X	X		X
48	5240	X	X		X
149	5745		X	X	
153	5765		X	X	
157	5785		X	X	
161	5805		X	X	
165	5825		x		

All Wifi channels used by the ClickShare system are 20MHz wide